

Gaposa Motor Programming

Initial Syncing – Choose channel (If multi-channel). Remove cover on battery. Locate LEFT programming button. Plug in motor. Using a paper clip, within 8 seconds of plugging in motor, press and hold left programming button until motor starts to move. Once motor moves and stops, repeatedly press direction on remote that the motor moved until it moves again.

Programming – Once you have sync'd remote, locate the RIGHT limit button on back of remote. Press and hold RIGHT button until the motor jogs (up and down motion on weight bar). Once the motor jogs move the screen to desired upper limit. Once at desired upper limit press and hold the STOP button until motor jogs to confirm. Once motor jogs to confirm, proceed to your bottom limit. Once at desired bottom limit, press and hold STOP button once more until the motor jogs to confirm bottom limit setting.

Adjusting limits – Once you have set your limits, if you need to adjust them you hold the right limit button and the button for the limit you want to adjust (RIGHT BUTTON & UP or RIGHT BUTTON & DOWN) until the unit jogs once. After that you can use the directional buttons to adjust the limit to your new desired position. Once at your new position simply press and hold the stop button until the unit jogs once again.

Factory reset sequence – Press and hold left programming button and stop button until motor jogs twice.